

NASH

*All radios listed are AM and pushbutton
unless otherwise noted*

Year	Model #	Additional Information
30's	9????	RCA Standard Manual Tune
?	ZN	Manual Tune
?		Green Front
46-48		Yellow Pushbuttons
46-48		Maroon Pushbuttons
50	NH1AC	
?	NH2AC	
53?	?	
?	NH5AC	
56	6MA	
57	76MA	

RAMBLER

*All radios are AM and
pushbutton
unless otherwise
noted*

Year	Model #
55?	NH1C
59	94MA
60	04MA
63	3TMR
64	4TMR
65	5TMR